



Princess



Princess – PCD45

Sing-a-long CD player with dual microphones for children



- * CD, CD-R, CD-RW
- * Dual microphones
- * CD program
- * CD repeat
- * Microphone volume control
- * Headphone jack
- * DC 9V jack (AC/DC adapter not included)
- * DC 9V 6x UM-2 / C 1.5V batteries
(Batteries not included)
- * Dim: 28,1 x 9,8 x 25,6 cm (B x T x H)
- * Barcode: 400 5425 000433
- * Packing: 4 pcs p. master carton